



# APOLLO3 PORTING GUIDE

# Contents

1.	Overview .....	4
2.	CMSIS Register Definitions .....	4
3.	Uniform Driver API .....	4
4.	HAL Status Return Values .....	5
5.	HAL Optional API Validation .....	5
6.	ADC HAL .....	5
6.1	Configuration .....	5
6.2	Operation .....	6
6.3	Interrupts .....	6
6.4	Data Movement .....	6
7.	CTIMER HAL .....	6
7.1	Global Enable .....	6
7.2	Auxiliary Configuration .....	6
7.3	Output Control .....	7
8.	GPIO HAL .....	8
8.1	Configuration .....	8
8.2	Operation .....	10
8.3	Interrupt functions .....	11
8.4	GPIO Read and Write Macros .....	12
8.5	Create the bsp_pins.src file .....	12
8.5.1	Creating a .src file .....	12
8.5.2	Build new pin files from the .src .....	13
8.6	Fast GPIO .....	14
9.	IOM HAL .....	16
9.1	Configuration .....	16
9.2	Operation .....	16
9.3	Interrupts .....	16
9.4	Data Movement .....	16
10.	IOS HAL .....	17
10.1	Configuration .....	17
10.2	Operation .....	17
10.3	Interrupts .....	17
10.4	Data Movement .....	18
11.	PDM HAL .....	18
11.1	Configuration .....	18
11.2	Operation .....	18
11.3	Interrupts .....	18
11.4	Data Movement .....	18
12.	PWRCTRL HAL .....	19
13.	STIMER HAL .....	20

14. UART HAL .....	20
14.1 Configuration .....	20
14.2 Operation .....	20
14.3 Interrupts .....	20
14.4 Data Movement .....	20

## Revision History

Date	Revision	History	Reviser
Sept 1, 2018	0.1	Initial Version	DM
Sept 10, 2018	0.2	Updates	DM
Sept 14, 2018	0.3	Fast GPIO	RH

# 1. Overview

This document is a guide to porting applications from the Apollo/Apollo2 SDK to the Apollo3 SDK. The Apollo3 SDK is a step towards incorporating more industry standard features into the AmbiqSuite. Specifically, the Apollo3 SDK supports:

- CMSIS standard register definitions, interrupt vectors, and intrinsics
- Uniform device driver model for communications APIs
- Consistent error checking and error code returns
- Device instances associated with device handle

## 2. CMSIS Register Definitions

The Apollo3 SDK supports the Cortex Microcontroller Software Interface Standard or CMSIS. Among other things, CMSIS defines a standard syntax for exposing MCU register definitions to software, interrupt vector naming and intrinsic function exposure. The Apollo SDK will deprecate the AM\_REG (Ambiq Micro Register) macros at the production release of the SDK. Any code from Apollo/Apollo2 implementations that directly use registers will need to port to the CMSIS standard.

## 3. Uniform Driver API

The majority of industry Cortex-M SDK implementations provide some level of commonality between similar devices (I2C, I2S, SPI, CAN, and UART). The Apollo/Apollo2 SDK organically grew the specific HAL device APIs based on the underlying features of the hardware and the need for efficient operation to demonstrate low-power. While this is necessary, it complicates the support model for many new customers as they need to learn the approach to each of these device APIs from scratch. The Uniform Device API is designed to establish a uniform set of APIs and requirement on the ADC, BLE, IOM, IOS, MSPI, PDM and UART devices in the Apollo3 MCU. These uniform APIs include the following generic functions:

- initialize – creates an instance of the given device interface and returns a handle to the instance for use with all other APIs.
- power\_control – provides a consistent interface to power-up and sleep the device (typically a device cannot be configured without first calling power\_control).
- configure – configures the entire device or a subset of the device resources (there can be multiple configure functions depending how the device provides resources).
- enable – enables a configured device to begin operation
- control – provides the ability to configure less used parameters or modes of the device
- interrupt\_enable – enable one or more interrupts from the device.
- interrupt\_disable - disable one or more interrupts from the device.
- interrupt\_status\_get – retrieve the current interrupts registered with the device.
- interrupt\_clear – clear one or more interrupts from the device.
- interrupt\_service – service an interrupt from the device.
- disable – disables a configured device to stop operation
- deinitialize – resets and returns a device instance

Not all devices require the full set as outlined above, but they do follow the same general pattern for initialization and shutdown. The differences are primarily in the calls made during operation of the device.

## 4. HAL Status Return Values

There is a generic set of return values that is used by all HAL routines included in `am_hal_status.h`. In some cases these values are extended for driver specific error codes. These values are:

```
//
// Global Status Returns
//
typedef enum
{
    AM_HAL_STATUS_SUCCESS,
    AM_HAL_STATUS_FAIL,
    AM_HAL_STATUS_INVALID_HANDLE,
    AM_HAL_STATUS_IN_USE,
    AM_HAL_STATUS_TIMEOUT,
    AM_HAL_STATUS_OUT_OF_RANGE,
    AM_HAL_STATUS_INVALID_ARG,
    AM_HAL_STATUS_INVALID_OPERATION,
    AM_HAL_STATUS_MEM_ERR,
    AM_HAL_STATUS_HW_ERR,
    AM_HAL_STATUS_MODULE_SPECIFIC_START = 0x08000000,
} am_hal_status_e;
```

## 5. HAL Optional API Validation

Several of the HAL drivers include optional code to validate parameters passed to the functions. While this code provides for additional error checking it also may cost efficiency. This code may be disabled by defining `AM_HAL_DISABLE_API_VALIDATION` in the compiled project.

## 6. ADC HAL

### 6.1 Configuration

All of the selectable configuration structures have been converted into enums instead of `#defines` for value definitions to aid in compile-time type safety. For example:

```
#define AM_HAL_ADC_LPMODE_0          AM_REG_ADC_CFG_LPMODE_MODE0
#define AM_HAL_ADC_LPMODE_1          AM_REG_ADC_CFG_LPMODE_MODE1
```

```
typedef enum
{
    AM_HAL_ADC_LPMODE0, // Low Latency Clock Mode. When set, HFRC and the adc_clk
                        // will remain on while in functioning in LPMODE0.
    AM_HAL_ADC_LPMODE1 // Powers down all circuitry and clocks associated with the
                        // ADC until the next trigger event. Between scans, the reference
                        // buffer requires up to 50us of delay from a scan trigger event
                        // before the conversion will commence while operating in this mode.
} am_hal_adc_lpmode_e;
```

Configuration of the ADC device can be mapped as follows:

Apollo/Apollo2 Function	Apollo3 Function
N/A	<code>am_hal_adc_initialize</code>
N/A	<code>am_hal_adc_power_control</code>
<code>am_hal_adc_config</code>	<code>am_hal_adc_configure</code>
<code>am_hal_adc_window_set</code>	<code>am_hal_adc_control(AM_HAL_ADC_REQ_WINDOW_CONFIG)</code>
<code>am_hal_adc_slot_config</code>	<code>am_hal_adc_configure_slot</code>
N/A	<code>am_hal_adc_configure_dma</code>
N/A	<code>am_hal_adc_deinitialize</code>

## 6.2 Operation

Operation of the ADC device can be mapped as follows:

Apollo/Apollo2 Function	Apollo3 Function
am_hal_adc_enable	am_hal_adc_enable
am_hal_adc_disable	am_hal_adc_disable
N/A	am_hal_adc_status_get
am_hal_adc_trigger	am_hal_adc_sw_trigger

## 6.3 Interrupts

Interrupt control of the ADC device can be mapped as follows:

Apollo/Apollo2 Function	Apollo3 Function
am_hal_adc_int_enable	am_hal_adc_interrupt_enable
am_hal_adc_int_disable	am_hal_adc_interrupt_disable
am_hal_adc_int_status_get	am_hal_adc_interrupt_status
am_hal_adc_int_clear	am_hal_adc_interrupt_clear

## 6.4 Data Movement

Apollo3 implements DMA to support the ADC device. With DMA the samples are transferred directly to SRAM and an interrupt is generated when the total number of samples is collected.

Raw data movement of the ADC device can be mapped as follows:

Apollo/Apollo2 Function	Apollo3 Function
am_hal_adc_fifo_peek	am_hal_adc_samples_read
am_hal_adc_fifo_pop	am_hal_adc_samples_read

# 7. CTIMER HAL

## 7.1 Global Enable

There is a new function that allows synchronized start of all of the CTIMERS. This overrides the individual enables of the CTIMERS and is designed to be used with the new stepper motor/pattern generation features of the CTIMER. The default is for all the timers to be enabled.

### Apollo3 Function

am\_hal\_ctimer\_globen

## 7.2 Auxiliary Configuration

There are two additional functions that allow setting the new AUX registers. These are mostly designed to be used with the new stepper motor/pattern generation features of the CTIMER.

### Apollo3 Function

am\_hal\_ctimer\_aux\_read

am\_hal\_ctimer\_aux\_compare\_set

am\_hal\_ctimer\_aux\_period\_set

## 7.3 Output Control

There is a new function which provides for coordinate routing of the new CTIMER output signal scheme to I/O pads. The function enforces the restrictions on the pad connectivity. It is recommended that the customer study the tables in the function implementation and the datasheet to get a sense for these restrictions.

### Apollo3 Function

am\_hal\_ctimer\_output\_config



## 8. GPIO HAL

The GPIO HAL implementation for Apollo3 has changed significantly from previous Apollo and Apollo2 SDKs. The hardware design for Apollo3 GPIO remains very similar to the previous products with a few new features added. The new GPIO features, however, do add some complexity that the new GPIO HAL makes more manageable for the user.

The previous software implementation was heavily dependent on macros for configuration and usage, which caused confusion to end users, especially with pin configuration, and contributed to code size due to the inline coding. The new implementation abstracts most of the configuration into the HAL with the caller supplying a single word containing all pin configuration parameters in a single 32-bit word defined by a standard C bitfield structure.

To further simplify pin definition, a tool is provided in order to easily define pin configurations. The pins are described in an ordinary text file and run through the script to produce compilable C code. See section 8.5 for details.

### 8.1 Configuration

Apollo/Apollo2 Function	Apollo3 Function
<b>am_hal_gpio_pin_config</b>	<b>am_hal_gpio_pinconfig</b>

This function is called when configuring a given pad for its ultimate function. The specified parameters (bfGpioCfg) are checked for compatibility with the specified pin. Any configuration or parameter errors result in an error return.

The prototype is `am_hal_gpio_pinconfig(uint32_t ui32Pin, am_hal_gpio_pincfg_t bfGpioCfg)`.

The `ui32Pin` parameter is simply the pin number to be configured.

**am\_hal\_gpio\_pincfg\_t** is a bitfield structure containing the following members:

**uFuncSel**        This is a value from 0-7 which will usually come from `am_hal_pin.h`.

**ePullup**        Many pads can supply a pullup resistor. For those that do, this member defines the value of that pullup. It is one of the following enumerations:

```
//
// Pullup configuration: am_hal_gpio_pincfg_t.ePullup enums
//
typedef enum
{
    //
    // Define pullup enums.
    // The 1.5K - 24K pullup values are valid for select I2C enabled pads.
    // The "weak" value is used for almost every other pad except pin 20.
    //
    AM_HAL_GPIO_PIN_PULLUP_NONE = 0x00,
    AM_HAL_GPIO_PIN_PULLUP_WEAK,
    AM_HAL_GPIO_PIN_PULLUP_1_5K,
    AM_HAL_GPIO_PIN_PULLUP_6K,
    AM_HAL_GPIO_PIN_PULLUP_12K,
    AM_HAL_GPIO_PIN_PULLUP_24K,
    AM_HAL_GPIO_PIN_PULLDOWN
} am_hal_gpio_pullup_e;
```

**eGPOutcfg**       This member is generally used when defining a pad as a GPIO output and defines the output type. It is one of the following enumerations:

```
//
// OUTCFG pad configuration: am_hal_gpio_pincfg_t.eGPOutcfg enums
// Applies only to GPIO configured pins.
// Ultimately maps to GPIOCFG.OUTCFG, bits [2:1].
//
typedef enum
{
```

```

    AM_HAL_GPIO_PIN_OUTCFG_DISABLE    = 0x0,
    AM_HAL_GPIO_PIN_OUTCFG_PUSHPULL   = 0x1,
    AM_HAL_GPIO_PIN_OUTCFG_OPENDRAIN  = 0x2,
    AM_HAL_GPIO_PIN_OUTCFG_TRISTATE    = 0x3
} am_hal_gpio_outcfg_e;

```

**eDriveStrength** For output configurations, many pads can be configured with various drive strengths. For those that do, this member defines that and will be one of the following enumerations:

```

//
// Pad Drive Strength configuration: am_hal_gpio_pincfg_t.eDriveStrength enums
//
typedef enum
{
    //
    // DRIVESTRENGTH is a 2-bit field.
    // bit0 maps to bit2 of a PADREG field.
    // bit1 maps to bit0 of an ALTPADCFG field.
    //
    AM_HAL_GPIO_PIN_DRIVESTRENGTH_2MA    = 0x0,
    AM_HAL_GPIO_PIN_DRIVESTRENGTH_4MA    = 0x1,
    AM_HAL_GPIO_PIN_DRIVESTRENGTH_8MA    = 0x2,
    AM_HAL_GPIO_PIN_DRIVESTRENGTH_12MA   = 0x3
} am_hal_gpio_drivestrength_e;

```

**eGPIInput** This member is generally used when defining a pad as a GPIO input and defines the input type. It is one of the following enumerations:

```

//
// GPIO input configuration: am_hal_gpio_pincfg_t.eGPIInput enums
// Applies only to GPIO configured pins!
// Ultimately maps to PADREG.INPEN, bit1.
//
typedef enum
{
    AM_HAL_GPIO_PIN_INPUT_AUTO           = 0x0,
    AM_HAL_GPIO_PIN_INPUT_NONE           = 0x0,
    AM_HAL_GPIO_PIN_INPUT_ENABLE         = 0x1
} am_hal_gpio_input_e;

```

**eGPRdZero** This member is generally used when defining a pad as a GPIO input and defines whether the pin value can be read or if it always reads as zero. It is one of the following enumerations:

```

//
// am_hal_gpio_pincfg_t.eGPRdZero
// For GPIO configurations (funcsel=3), the pin value can be read or 0 can be
// forced as the read value.
//
typedef enum
{
    AM_HAL_GPIO_PIN_RDZERO_READPIN       = 0x0,
    AM_HAL_GPIO_PIN_RDZERO_ZERO          = 0x1
} am_hal_gpio_readen_e;

```

**eIntDir** This member is used when interrupts are to be enabled for a pad. It is one of the following enumerations:

```

//
// GPIO interrupt direction configuration: am_hal_gpio_pincfg_t.eIntDir enums
// Note: Setting INTDIR_NONE has the side-effect of disabling being able to
//       read a pin - the pin will always read back as 0.
//
typedef enum
{
    // Bit1 of these values maps to GPIOCFG.INCFG (b0).
    // Bit0 of these values maps to GPIOCFG.INTD (b3).
    AM_HAL_GPIO_PIN_INTDIR_LO2HI         = 0x0,

```

```

    AM_HAL_GPIO_PIN_INTDIR_HI2LO      = 0x1,
    AM_HAL_GPIO_PIN_INTDIR_NONE       = 0x2,
    AM_HAL_GPIO_PIN_INTDIR_BOTH       = 0x3
} am_hal_gpio_intdir_e;

```

**ePowerSw** A select number of pins can be configured to source or sink current (see datasheet for which pins support these functions). For pins that support it, it is one of the following enumerations:

```

//
// Power Switch configuration: am_hal_gpio_pincfg_t.ePowerSw enums
//
typedef enum
{
    AM_HAL_GPIO_PIN_POWERSW_NONE,
    AM_HAL_GPIO_PIN_POWERSW_VDD,
    AM_HAL_GPIO_PIN_POWERSW_VSS,
    AM_HAL_GPIO_PIN_POWERSW_INVALID,
} am_hal_gpio_powersw_e;

```

**uIOMnum** This member is used when a pad is defined to be a chip enable and designates the IO Master number (0-5) or MSPI (6) that the CE is to be used for. Most pads can be configured as a chip enable with each pad supporting 4 combinations of IOM/MSPI and channel numbers. See the datasheet for a table of these combinations. This member is always a value of 0-5 or 6.

**uNCE** This member is used when a pad is defined to be a chip enable and is used in conjunction with uIOMnum to define the CE number for a particular SPI device. It is always a value of 0-3.

**eCEpol** This member is used when a pad is defined to be a chip enable and specifies the polarity of the CE enable. It is one of the following enumerations:

```

//
// nCE polarity configuration: am_hal_gpio_pincfg_t.eCEpol enums
//
typedef enum
{
    AM_HAL_GPIO_PIN_CEPOL_ACTIVELOW      = 0x0,
    AM_HAL_GPIO_PIN_CEPOL_ACTIVEHIGH     = 0x1
} am_hal_gpio_cepol_e;

```

## 8.2 Operation

### Apollo/Apollo2 Functions

**am\_hal\_gpio\_input\_bit\_read**  
**am\_hal\_gpio\_output\_bit\_read**  
**am\_hal\_gpio\_enable\_bit\_get**

### Apollo3 Function

**am\_hal\_gpio\_state\_read**

The new Apollo3 **am\_hal\_gpio\_state\_read** function is used for reading GPIO values.

The prototype is `am_hal_gpio_state_read(uint32_t ui32Pin, am_hal_gpio_read_type_e eReadType, uint32_t *pui32ReadState)`.

ui32Pin is the pin number to be read.

eReadType is one of the following enumerations:

```

typedef enum
{
    AM_HAL_GPIO_INPUT_READ,
    AM_HAL_GPIO_OUTPUT_READ,
    AM_HAL_GPIO_ENABLE_READ
}

```

```
} am_hal_gpio_read_type_e;
```

pui32ReadState is a pointer to the variable to receive the read value of the pin.

Apollo/Apollo2 Functions	Apollo3 Function
<b>am_hal_gpio_out_bit_set</b>	<b>am_hal_gpio_state_write</b>
<b>am_hal_gpio_out_bit_clear</b>	
<b>am_hal_gpio_out_bit_toggle</b>	

The new Apollo3 **am\_hal\_gpio\_state\_write** function is used for writing GPIO values.

The prototype is `am_hal_gpio_state_write(uint32_t ui32Pin, am_hal_gpio_write_type_e eWriteType)`.

ui32Pin is the pin number to be read.

eWriteType is one of the following enumerations:

```
typedef enum
{
    AM_HAL_GPIO_OUTPUT_CLEAR,
    AM_HAL_GPIO_OUTPUT_SET,
    AM_HAL_GPIO_OUTPUT_TOGGLE,
    AM_HAL_GPIO_OUTPUT_TRISTATE_DISABLE,
    AM_HAL_GPIO_OUTPUT_TRISTATE_ENABLE,
    AM_HAL_GPIO_OUTPUT_TRISTATE_TOGGLE
} am_hal_gpio_write_type_e;
```

## 8.3 Interrupt functions

As with other peripherals, pins configured as GPIOs can be configured to provide interrupts. The HAL provides several functions to support this functionality.

Apollo/Apollo2 Functions	Apollo3 Function
<b>am_hal_gpio_int_enable</b>	<b>am_hal_gpio_interrupt_enable</b>
<b>am_hal_gpio_int_enable_get</b>	
<b>am_hal_gpio_int_disable</b>	<b>am_hal_gpio_interrupt_disable</b>
<b>am_hal_gpio_int_clear</b>	<b>am_hal_gpio_interrupt_clear</b>
<b>am_hal_gpio_int_set</b>	
<b>am_hal_gpio_int_status_get</b>	<b>am_hal_gpio_interrupt_status_get</b>
<b>am_hal_gpio_int_service</b>	<b>am_hal_gpio_interrupt_service</b>
<b>am_hal_gpio_int_register</b>	<b>am_hal_gpio_interrupt_register</b>
<b>am_hal_gpio_int_polarity_bit_get</b>	

The **am\_hal\_gpio\_interrupt\_enable** function enables the given interrupt(s). Only bits 0-49 are valid in the mask.

The **am\_hal\_gpio\_interrupt\_disable** function disables the given interrupt(s). Only bits 0-49 are valid in the mask.

The **am\_hal\_gpio\_interrupt\_clear** function clears the given interrupt(s). Only bits 0-49 are valid in the mask. This function is often used in conjunction with `am_hal_gpio_interrupt_status_get()`, with the returned `IntStatus` used as the input to this function.

The **am\_hal\_gpio\_interrupt\_status\_get** function returns the current interrupt status. It can return the status of every interrupt (`bEnabledOnly=false`) or the status of only those that are enabled (`bEnabledOnly=true`). The 64bit variable pointed to be `pui64IntStatus` contains the return status.

The **am\_hal\_gpio\_interrupt\_service** function is an overall service routine for GPIO interrupts. It is called by `am_gpio_isr()`, which also calls `am_hal_gpio_interrupt_status_get()` to use as an input parameter to this function. The general usage is that the application calls `am_hal_gpio_interrupt_register()` to register a callback routine that

this routine will call when the registered interrupt occurs. The application also supplies the main handler, `am_gpio_isr()`.

The `am_hal_gpio_interrupt_register` function is called by the application for registering specific handlers to specific GPIO interrupts.

## 8.4 GPIO Read and Write Macros

While the primary read and write functions will suffice for virtually all applications, there may be situations where minimal response time is required. To support these situations a set of macros are provided which provide minimal inline code for accessing GPIOs.

Advantages to usage of these macros include faster GPIO read or write access times, no function call overhead, and simple read return values.

Drawbacks to usage of these macros include no error checking, larger resultant code size, no guaranteed atomicity, and risk to general safety.

The “\_read” macros are counterparts to the enumerations used for the `am_hal_gpio_state_read()` function.

Likewise, the “\_set, \_clear, \_toggle”) macros are counterparts to the enumerations used for the `am_hal_gpio_state_write()` function.

### Apollo3 GPIO Macros

<code>am_hal_gpio_input_read(n)</code>
<code>am_hal_gpio_output_read(n)</code>
<code>am_hal_gpio_enable_read(n)</code>
<code>am_hal_gpio_output_clear(n)</code>
<code>am_hal_gpio_output_set(n)</code>
<code>am_hal_gpio_output_toggle(n)</code>
<code>am_hal_gpio_output_tristate_enable(n)</code>
<code>am_hal_gpio_output_tristate_disable(n)</code>
<code>am_hal_gpio_output_tristate_toggle(n)</code>

## 8.5 Create the `bsp_pins.src` file

The file `bsp_pins.src` is a simple text file containing names, keywords, and values that describe each pin. The text file is subsequently provided as input to a Python script that generates two files: `am_bsp_pins.c` and `am_bsp_pins.h`. These two C files contain each of the pins bitfield structures that are passed along to `am_hal_gpio_pinconfig()`.

### 8.5.1 Creating a .src file

Note - the .src file should contain no tab characters (only spaces).  
Also, indentation is important. A tab indentation of 4 spaces is recommended.

Each pin entry takes the form:

```
pin
    name           = UART_TX
    desc           = This pin is the COM_UART transmit pin.
    pinnum         = 35
```

```
func_sel      = AM_HAL_PIN_35_UART1TX
drvstrength   = 2
```

While there are about a dozen keywords (parameters) available, only the parameters required to define a pin need be included in any particular definition when defined globally. If defined in a local variable (stack), all unused fields must be specifically set to 0.

The keywords used in the file are:

name	The name to be used for the pin. This name will be used as a base for generating defines. Each pin name must be unique.
desc	Optional: A description, if provided, will appear in the generated header file.
funcsel	A value 0-7, or the equivalent AM_HAL_PIN_nn_xxxx macro from am_hal_pin.h. Note that the AM_HAL_PIN_nn_xxxx nomenclature is preferred.
pinnum	The pin number for the pin being defined (0-49).
drvstrength	One of: 2, 4, 8, or 12. If not provided, 2 is default.
GPOutCfg	Typically used if the pin is being defined as GPIO (funcsel=3). One of: disable, pushpull, opendrain, tristate. *
GPinput	Only used if the pin is being defined as GPIO (funcsel=3). One of: true, false.
GPRdZero	One of: readpin, zero (or true or false).
intdir	One of: none, lo2hi, hi2lo, either. Note - does not enable any interrupt. Only configures the direction for when it is enabled.
pullup	One of: none, 1_5K, 6K, 12K, 24K. Also acceptable is a define (e.g. AM_HAL_GPIO_PIN_PULLUP_1_5K).
PowerSw	One of: VDD or VSS. Also acceptable is a define (e.g. AM_HAL_GPIO_PIN_POWERSW_VDD).

The following 3 parameters only apply when the pin is being defined as a chip enable, i.e. a CE for a SPI or MSPI device.

IOMnum	The IOM number pertaining to the CE. 0-5 for SPI, 6 for MSPI.
CEnum	A value from 0-3 representing the chip enable channel number. Results in a C define of the form: #define AM_BSP_<name>_CHNL <CEnum>
CEpol	Designates the chip enable polarity, active high or active low. One of: LOW (default) or HIGH.

## 8.5.2 Build new pin files from the .src

Each bsp directory contains a Makefile that can be used to completely rebuild the BSP by simply typing “make” on the command line. A rebuild might be required, for instance, if the .src file is updated or if a BSP C function is modified. The first step of the build process is the creation of the am\_bsp\_pins.c and am\_bsp\_pins.h files using the .src file as input. Once those two files have been created, the Makefile then builds the BSP itself.

Alternatively, the am\_bsp\_pins.c and am\_bsp\_pins.h can be manually created by using the script found at tools/bsp\_generator/pinconfig.py. The script must be run twice, once to create the .c file and again to create the .h file. The basic command line is:

```
pinconfig.py bsp_pins.src C >am_bsp_pins.c
pinconfig.py bsp_pins.src H >am_bsp_pins.h
```

## 8.6 Fast GPIO

The Apollo3 MCU introduced an alternative method of setting and clearing GPIOs, termed Fast GPIO. The set and clear registers for Fast GPIO operation are architecturally situated near the MCU core (in the APBDMA named block) such that GPIO accesses can be handled with minimal latency. The Apollo3 HAL supports these Apollo3 specific functions.

One of the intended usages of Fast GPIO is in “bit-banging” operations for up to 8 bits in parallel, with each pin controlled with a single bit in the SETCLEAR register. This set/clear methodology imposes a limitation that only certain pins can be controlled with each bit. That control can be seen in the following matrix (as well as a similar matrix in `am_hal_gpio.h`) that relates the control bit to the pins that can be controlled by that bit.

BIT		PIN controlled by bit						
0		0	8	16	24	32	40	48
1		1	9	17	25	33	41	49
2		2	10	18	26	34	42	
3		3	11	19	27	35	43	
4		4	12	20	28	36	44	
5		5	13	21	29	37	45	
6		6	14	22	30	38	46	
7		7	15	23	31	39	47	

Fast GPIO pin configuration is similar to normal pin configuration, but a new function is provided to facilitate it. Further it is recommended that prior to configuring a pin that the state be initialized using `am_hal_gpio_fastgpio_disable()` and `am_hal_gpio_fastgpio_clr()/set()`.

The prototype of the Fast GPIO pin configuration function is:

```
am_hal_gpio_fast_pinconfig(uint64_t ui64PinMask, am_hal_gpio_pincfg_t bfGpioCfg, uint32_t ui32Masks[]).
```

Where `ui64PinMask` is a mask of the pins to be configured.

For the most efficient access, the Fast GPIO implementation is supported by various macros instead of functions.

`am_hal_gpio_fastgpio_enable(n)` – Typically used after pin configuration to enable fast gpio for the specified pin.

`am_hal_gpio_fastgpio_disable(n)` – Disable fast gpio on the specified pin.

`am_hal_gpio_fastgpio_set(n)` – Set the given pin high.

`am_hal_gpio_fastgpio_clr(n)` – Clear the value on the given pin.

`am_hal_gpio_fastgpio_setmsk(n)` – Set the given pins high.

`am_hal_gpio_fastgpio_clrmsk(n)` – Clear the values on the given pins.

`am_hal_gpio_fastgpio_wrrval(val)` – Write a value to all of the Fast GPIO configured pins.

Finally, note that each specified pin must be on a unique row. Even though this restriction is not strictly enforced by `am_hal_gpio_fast_pinconfig()`,

For example, the following call will configure 8 pins, pins 48, 41, 34, 27, 20, 13, 6, 15, for output of fast gpio.

```
am_hal_gpio_fast_pinconfig((uint64_t)0x000102040810A040, g_AM_HAL_GPIO_OUTPUT, 0);
```

Each pin would then need `am_hal_gpio_fastgpio_enable()`, after which the set and clr macros could be used.

Note in this example that pin 48 would be controlled by bit0, 41 by bit1, 34 by bit2, 27 by bit3, 20 by bit4, 13 by bit5, 6 by bit6, and 15 by bit 7.



## 9. IOM HAL

The Apollo3 IOM HAL interface has been greatly simplified from Apollo/Apollo2. Support for a wide variety of blocking, queue, and nonblocking read/write operations has been reduced to just three transfer functions.

### 9.1 Configuration

All of the selectable configuration structures have been converted into enums instead of #defines for value definitions to aid in compile-time type safety. Configuration of the IOM device can be mapped as follows:

Apollo/Apollo2 Function	Apollo3 Function
N/A	<b>am_hal_iom_initialize</b>
N/A	<b>am_hal_iom_power_ctrl</b>
<b>am_hal_iom_config</b>	<b>am_hal_iom_configure</b>
N/A	<b>am_hal_iom_control</b>
N/A	<b>am_hal_iom_deinitialize</b>

### 9.2 Operation

Operation of the IOM device can be mapped as follows:

Apollo/Apollo2 Function	Apollo3 Function
<b>am_hal_iom_enable</b>	<b>am_hal_iom_enable</b>
<b>am_hal_iom_disable</b>	<b>am_hal_iom_disable</b>
<b>am_hal_iom_status_get</b>	<b>am_hal_iom_status_get</b>
<b>am_hal_iom_error_status_get</b>	N/A

### 9.3 Interrupts

Interrupt control of the IOM device can be mapped as follows:

Apollo/Apollo2 Function	Apollo3 Function
<b>am_hal_iom_int_enable</b>	<b>am_hal_iom_interrupt_enable</b>
<b>am_hal_iom_int_enable_get</b>	N/A
<b>am_hal_iom_int_disable</b>	<b>am_hal_iom_interrupt_disable</b>
<b>am_hal_iom_int_status_get</b>	<b>am_hal_iom_interrupt_status_get</b>
<b>am_hal_iom_int_set</b>	N/A
<b>am_hal_iom_int_clear</b>	<b>am_hal_iom_interrupt_clear</b>
<b>am_hal_iom_int_service</b>	<b>am_hal_iom_interrupt_service</b>

### 9.4 Data Movement

Apollo3 implements DMA to support the IOM devices. With DMA the samples are transferred directly to SRAM and an interrupt is generated when the total number of samples is collected. In addition, Apollo3 supports a Command Queue for each IOM device. The Command Queue is used inside the non-blocking transfer function to provide queued request for DMA transfer.

The data movement of the IOM device can be mapped as follows:

Apollo/Apollo2 Function	Apollo3 Function
<b>am_hal_iom_spi_write_nq</b> <b>am_hal_iom_spi_read_nq</b> <b>am_hal_iom_i2c_write_nq</b> <b>am_hal_iom_i2c_read_nq</b>	<b>am_hal_iom_blocking_transfer</b>
<b>am_hal_iom_spi_write_nb</b> <b>am_hal_iom_spi_read_nb</b>	<b>am_hal_iom_nonblocking_transfer</b>

am_hal_iom_queue_spi_write	
am_hal_iom_queue_spi_read	
am_hal_iom_i2c_write_nb	
am_hal_iom_i2c_read_nb	
am_hal_iom_spi_full duplex_nq	N/A

The Apollo3 IOM HAL data movement operations have been greatly simplified from the Apollo/Apollo2 equivalents. There are essentially two primary transfer functions that can be used for half-duplex send (TX) or receive (RX) or full-duplex operation. A transfer can be called with either the blocking or nonblocking interface. The blocking interface returns after the transfer has been completed. The nonblocking interface returns after the transfer has been scheduled. There is an optional callback that can be supplied to the nonblocking interface to notify the application when the operation is complete.

## 10. IOS HAL

The Apollo3 IOS HAL interface has been greatly simplified from Apollo/Apollo2. Support for direct LRAM interaction has been deprecated in preference to the FIFO interface.

### 10.1 Configuration

Configuration of the IOS device can be mapped as follows:

Apollo/Apollo2 Function	Apollo3 Function
N/A	am_hal_ios_initialize
am_hal_ios_pwrctrl_enable	am_hal_ios_power_ctrl
am_hal_ios_pwrctrl_disable	
am_hal_ios_config	am_hal_ios_configure
N/A	am_hal_ios_control
N/A	am_hal_ios_uninitialize

### 10.2 Operation

Operation of the IOS device can be mapped as follows:

Apollo/Apollo2 Function	Apollo3 Function
am_hal_ios_enable	am_hal_ios_enable
am_hal_ios_disable	am_hal_ios_disable

### 10.3 Interrupts

Interrupt control of the IOS device can be mapped as follows:

Apollo/Apollo2 Function	Apollo3 Function
am_hal_ios_host_int_set	am_hal_ios_control(AM_HAL_IOS_REQ_HOST_INT*)
am_hal_ios_host_int_clear	
am_hal_ios_host_int_get	
am_hal_ios_host_int_enable	
	N/A
	N/A
	N/A
am_hal_ios_access_int_enable	N/A
am_hal_ios_access_int_enable_get	N/A
am_hal_ios_access_int_disable	N/A
am_hal_ios_access_int_clear	N/A
am_hal_ios_access_int_set	N/A
am_hal_ios_access_int_status_get	N/A
am_hal_ios_int_enable	am_hal_ios_interrupt_enable
am_hal_ios_int_disable	am_hal_ios_interrupt_disable

<code>am_hal_ios_int_clear</code>	<code>am_hal_ios_interrupt_clear</code>
<code>am_hal_ios_int_set</code>	N/A
<code>am_hal_ios_int_status_get</code>	<code>am_hal_ios_interrupt_status_get</code>
<code>am_hal_ios_fifo_service</code>	<code>am_hal_ios_interrupt_service</code>

## 10.4 Data Movement

Apollo/Apollo2 Function	Apollo3 Function
<code>am_hal_ios_fifo_space_left</code>	<code>am_hal_ios_fifo_space_left</code>
<code>am_hal_ios_fifo_space_used</code>	<code>am_hal_ios_fifo_space_used</code>
<code>am_hal_ios_fifo_write</code>	<code>am_hal_ios_fifo_write</code>
<code>am_hal_ios_fifo_write_simple</code>	N/A
<code>am_hal_ios_fifo_ptr_set</code>	N/A
<code>am_hal_ios_update_fifoctr</code>	<code>am_hal_ios_control(AM_HAL_IOS_REQ_FIFO_UPDATE_CTRL)</code>
<code>am_hal_ios_read_poll_complete</code>	<code>am_hal_ios_control(AM_HAL_IOS_REQ_READ_POLL)</code>
<code>am_hal_ios_lram_write</code>	N/A

## 11. PDM HAL

### 11.1 Configuration

The Apollo2 PDM HAL provided a number of macros to configure individual registers of the PDM block. These macros have been deprecated. In addition, the Apollo3 HAL follows the practice of using enums and booleans instead of discrete `uint32_t` for configuration parameters.

Apollo2 Function	Apollo3 Function
N/A	<code>am_hal_pdm_initialize</code>
N/A	<code>am_hal_pdm_power_control</code>
<code>am_hal_pdm_config</code>	<code>am_hal_pdm_configure</code>
N/A	<code>am_hal_pdm_deinitialize</code>

### 11.2 Operation

Apollo2 Function	Apollo3 Function
<code>am_hal_pdm_enable</code>	<code>am_hal_pdm_enable</code>
<code>am_hal_pdm_disable</code>	<code>am_hal_pdm_disable</code>

### 11.3 Interrupts

Apollo2 Function	Apollo3 Function
<code>am_hal_pdm_int_enable</code>	<code>am_hal_pdm_interrupt_enable</code>
<code>am_hal_pdm_int_disable</code>	<code>am_hal_pdm_interrupt_disable</code>
<code>am_hal_pdm_int_clear</code>	<code>am_hal_pdm_interrupt_clear</code>
<code>am_hal_pdm_int_status_get</code>	<code>am_hal_pdm_interrupt_status_get</code>

### 11.4 Data Movement

Apollo2 Function	Apollo3 Function
<code>am_hal_pdm_fifo_depth_read</code>	N/A
<code>am_hal_pdm_fifo_data_read</code>	N/A
<code>am_hal_pdm_fifo_flush</code>	<code>am_hal_pdm_fifo_flush</code>

N/A

am\_hal\_pdm\_dma\_start

## 12. PWRCTRL HAL

The Apollo3 SDK PWRCTRL is fairly consistent with Apollo/Apollo2 SDK. The biggest difference is the mapping of peripheral and memory configurations to enums as follows:

```
typedef enum
{
    AM_HAL_PWRCTRL_PERIPH_NONE,
    AM_HAL_PWRCTRL_PERIPH_IOS,
    AM_HAL_PWRCTRL_PERIPH_IOM0,
    AM_HAL_PWRCTRL_PERIPH_IOM1,
    AM_HAL_PWRCTRL_PERIPH_IOM2,
    AM_HAL_PWRCTRL_PERIPH_IOM3,
    AM_HAL_PWRCTRL_PERIPH_IOM4,
    AM_HAL_PWRCTRL_PERIPH_IOM5,
    AM_HAL_PWRCTRL_PERIPH_UART0,
    AM_HAL_PWRCTRL_PERIPH_UART1,
    AM_HAL_PWRCTRL_PERIPH_ADC,
    AM_HAL_PWRCTRL_PERIPH_SCARD,
    AM_HAL_PWRCTRL_PERIPH_MSPI,
    AM_HAL_PWRCTRL_PERIPH_PDM,
    AM_HAL_PWRCTRL_PERIPH_BLE1,
    AM_HAL_PWRCTRL_PERIPH_MAX
} am_hal_pwrctrl_periph_e;
```

```
typedef enum
{
    AM_HAL_PWRCTRL_MEM_NONE,
    AM_HAL_PWRCTRL_MEM_SRAM_8K_DTCM,
    AM_HAL_PWRCTRL_MEM_SRAM_32K_DTCM,
    AM_HAL_PWRCTRL_MEM_SRAM_64K_DTCM,
    AM_HAL_PWRCTRL_MEM_SRAM_96K,
    AM_HAL_PWRCTRL_MEM_SRAM_128K,
    AM_HAL_PWRCTRL_MEM_SRAM_160K,
    AM_HAL_PWRCTRL_MEM_SRAM_192K,
    AM_HAL_PWRCTRL_MEM_SRAM_224K,
    AM_HAL_PWRCTRL_MEM_SRAM_256K,
    AM_HAL_PWRCTRL_MEM_SRAM_288K,
    AM_HAL_PWRCTRL_MEM_SRAM_320K,
    AM_HAL_PWRCTRL_MEM_SRAM_352K,
    AM_HAL_PWRCTRL_MEM_SRAM_384K,
    AM_HAL_PWRCTRL_MEM_FLASH_512K,
    AM_HAL_PWRCTRL_MEM_FLASH_1M,
    AM_HAL_PWRCTRL_MEM_CACHE,
    AM_HAL_PWRCTRL_MEM_ALL,
    AM_HAL_PWRCTRL_MEM_MAX
} am_hal_pwrctrl_mem_e;
```

The function mappings are almost equivalent.

Apollo2 Function	Apollo3 Function
am_hal_pwrctrl_periph_enable	am_hal_pwrctrl_periph_enable
am_hal_pwrctrl_periph_disable	am_hal_pwrctrl_periph_disable
N/A	am_hal_pwrctrl_periph_enabled
am_hal_pwrctrl_memory_enable	am_hal_pwrctrl_memory_enable
am_hal_pwrctrl_bucks_init	N/A
am_hal_pwrctrl_bucks_enable	
am_hal_pwrctrl_bucks_disable	
am_hal_pwrctrl_low_power_init	am_hal_pwrctrl_low_power_init

## 13. STIMER HAL

The Apollo3 SDK STIMER HAL is 100% compatible with Apollo2, except for the addition of the following functions to set and read back the 4 32-bit words of NVRAM.

### Apollo3 Function

**am\_hal\_stimer\_nvram\_set**

**am\_hal\_stimer\_nvram\_get**

## 14. UART HAL

The Apollo3 SDK UART HAL greatly simplifies the HAL API from Apollo/Apollo2 HAL while deprecating the concept of string/char processing and embedding TX/RX buffering into the HAL.

### 14.1 Configuration

Apollo/Apollo2 Function	Apollo3 Function
N/A	<b>am_hal_uart_initialize</b>
<b>am_hal_uart_pwrctrl_enable</b> <b>am_hal_uart_pwrctrl_disable</b> <b>am_hal_uart_power_on_restore</b> <b>am_hal_uart_power_off_save</b>	<b>am_hal_uart_power_control</b>
<b>am_hal_uart_config</b> <b>am_hal_uart_clock_enable</b> <b>am_hal_uart_clock_disable</b> <b>am_hal_uart_fifo_config</b> <b>am_hal_uart_init_buffered</b>	<b>am_hal_uart_configure</b>
N/A	<b>am_hal_uart_deinitialize</b>

### 14.2 Operation

Apollo/Apollo2 Function	Apollo3 Function
<b>am_hal_uart_enable</b>	N/A
<b>am_hal_uart_disable</b>	N/A

### 14.3 Interrupts

Apollo/Apollo2 Function	Apollo3 Function
<b>am_hal_uart_int_enable</b>	<b>am_hal_uart_interrupt_enable</b>
<b>am_hal_uart_int_disable</b>	<b>am_hal_uart_interrupt_disable</b>
<b>am_hal_uart_int_clear</b>	<b>am_hal_uart_interrupt_clear</b>
<b>am_hal_uart_int_status_get</b>	<b>am_hal_uart_interrupt_status_get</b>
<b>am_hal_uart_service_buffered</b> <b>am_hal_uart_service_buffered_timeout_save</b>	<b>am_hal_uart_interrupt_service</b>
<b>am_hal_uart_int_enable_get</b>	N/A

### 14.4 Data Movement

Apollo/Apollo2 Function	Apollo3 Function
<b>am_hal_uart_char_transmit_polled</b>	<b>am_hal_uart_transfer</b>

am_hal_uart_string_transmit_polled
am_hal_uart_char_receive_polled
am_hal_uart_line_receive_polled
am_hal_uart_char_transmit_buffered
am_hal_uart_string_transmit_buffered
am_hal_uart_char_receive_buffered

N/A
-----

am_hal_uart_tx_flush
----------------------

am_hal_uart_flags_get
-----------------------

am_hal_uart_flags_get
-----------------------

am_hal_uart_status_get
------------------------

am_hal_uart_get_status_buffered
---------------------------------

## Contact Information

<b>Address</b>	Ambiq Micro, Inc. 6500 River Place Blvd. Building 7, Suite 200 Austin, TX 78730
<b>Phone</b>	+1 (512) 879-2850
<b>Website</b>	<a href="http://www.ambiqmicro.com">http://www.ambiqmicro.com</a>
<b>General Information</b>	<a href="mailto:info@ambiqmicro.com">info@ambiqmicro.com</a>
<b>Sales</b>	<a href="mailto:sales@ambiqmicro.com">sales@ambiqmicro.com</a>
<b>Technical Support</b>	<a href="mailto:support@ambiqmicro.com">support@ambiqmicro.com</a>

## Legal Information and Disclaimers

AMBIQ MICRO INTENDS FOR THE CONTENT CONTAINED IN THE DOCUMENT TO BE ACCURATE AND RELIABLE. THIS CONTENT MAY, HOWEVER, CONTAIN TECHNICAL INACCURACIES, TYPOGRAPHICAL ERRORS OR OTHER MISTAKES. AMBIQ MICRO MAY MAKE CORRECTIONS OR OTHER CHANGES TO THIS CONTENT AT ANY TIME. AMBIQ MICRO AND ITS SUPPLIERS RESERVE THE RIGHT TO MAKE CORRECTIONS, MODIFICATIONS, ENHANCEMENTS, IMPROVEMENTS AND OTHER CHANGES TO ITS PRODUCTS, PROGRAMS AND SERVICES AT ANY TIME OR TO DISCONTINUE ANY PRODUCTS, PROGRAMS, OR SERVICES WITHOUT NOTICE.

THE CONTENT IN THIS DOCUMENT IS PROVIDED "AS IS". AMBIQ MICRO AND ITS RESPECTIVE SUPPLIERS MAKE NO REPRESENTATIONS ABOUT THE SUITABILITY OF THIS CONTENT FOR ANY PURPOSE AND DISCLAIM ALL WARRANTIES AND CONDITIONS WITH REGARD TO THIS CONTENT, INCLUDING BUT NOT LIMITED TO, ALL IMPLIED WARRANTIES AND CONDITIONS OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE AND NON-INFRINGEMENT OF ANY THIRD PARTY INTELLECTUAL PROPERTY RIGHT.

AMBIQ MICRO DOES NOT WARRANT OR REPRESENT THAT ANY LICENSE, EITHER EXPRESS OR IMPLIED, IS GRANTED UNDER ANY PATENT RIGHT, COPYRIGHT, MASK WORK RIGHT, OR OTHER INTELLECTUAL PROPERTY RIGHT OF AMBIQ MICRO COVERING OR RELATING TO THIS CONTENT OR ANY COMBINATION, MACHINE, OR PROCESS TO WHICH THIS CONTENT RELATE OR WITH WHICH THIS CONTENT MAY BE USED.

USE OF THE INFORMATION IN THIS DOCUMENT MAY REQUIRE A LICENSE FROM A THIRD PARTY UNDER THE PATENTS OR OTHER INTELLECTUAL PROPERTY OF THAT THIRD PARTY, OR A LICENSE FROM AMBIQ MICRO UNDER THE PATENTS OR OTHER INTELLECTUAL PROPERTY OF AMBIQ MICRO.

INFORMATION IN THIS DOCUMENT IS PROVIDED SOLELY TO ENABLE SYSTEM AND SOFTWARE IMPLEMENTERS TO USE AMBIQ MICRO PRODUCTS. THERE ARE NO EXPRESS OR IMPLIED COPYRIGHT LICENSES GRANTED HEREUNDER TO DESIGN OR FABRICATE ANY INTEGRATED CIRCUITS OR INTEGRATED CIRCUITS BASED ON THE INFORMATION IN THIS DOCUMENT. AMBIQ MICRO RESERVES THE RIGHT TO MAKE CHANGES WITHOUT FURTHER NOTICE TO ANY PRODUCTS HEREIN. AMBIQ MICRO MAKES NO WARRANTY, REPRESENTATION OR GUARANTEE REGARDING THE SUITABILITY OF ITS PRODUCTS FOR ANY PARTICULAR PURPOSE, NOR DOES AMBIQ MICRO ASSUME ANY LIABILITY ARISING OUT OF THE APPLICATION OR USE OF ANY PRODUCT OR CIRCUIT, AND SPECIFICALLY DISCLAIMS ANY AND ALL LIABILITY, INCLUDING WITHOUT LIMITATION CONSEQUENTIAL OR INCIDENTAL DAMAGES. "TYPICAL" PARAMETERS WHICH MAY BE PROVIDED IN AMBIQ MICRO DATA SHEETS AND/OR SPECIFICATIONS CAN AND DO VARY IN DIFFERENT APPLICATIONS AND ACTUAL PERFORMANCE MAY VARY OVER TIME. ALL OPERATING PARAMETERS, INCLUDING "TYPICALS" MUST BE VALIDATED FOR EACH CUSTOMER APPLICATION BY CUSTOMER'S TECHNICAL EXPERTS. AMBIQ MICRO DOES NOT CONVEY ANY LICENSE UNDER NEITHER ITS PATENT RIGHTS NOR THE RIGHTS OF OTHERS. AMBIQ MICRO PRODUCTS ARE NOT DESIGNED, INTENDED, OR AUTHORIZED FOR USE AS COMPONENTS IN SYSTEMS INTENDED FOR SURGICAL IMPLANT INTO THE BODY, OR OTHER APPLICATIONS INTENDED TO SUPPORT OR SUSTAIN LIFE, OR FOR ANY OTHER APPLICATION IN WHICH THE FAILURE OF THE AMBIQ MICRO PRODUCT COULD CREATE A SITUATION WHERE PERSONAL INJURY OR DEATH MAY OCCUR. SHOULD BUYER PURCHASE OR USE AMBIQ MICRO PRODUCTS FOR ANY SUCH UNINTENDED OR UNAUTHORIZED APPLICATION, BUYER SHALL INDEMNIFY AND HOLD AMBIQ MICRO AND ITS OFFICERS, EMPLOYEES, SUBSIDIARIES, AFFILIATES, AND DISTRIBUTORS HARMLESS AGAINST ALL CLAIMS, COSTS, DAMAGES, AND EXPENSES, AND REASONABLE ATTORNEY FEES ARISING OUT OF, DIRECTLY OR INDIRECTLY, ANY CLAIM OF PERSONAL INJURY OR DEATH ASSOCIATED WITH SUCH UNINTENDED OR UNAUTHORIZED USE, EVEN IF SUCH CLAIM ALLEGES THAT AMBIQ MICRO WAS NEGLIGENT REGARDING THE DESIGN OR MANUFACTURE OF THE PART.